



Exploded

E7067 Beautydumbbellrack



please note :prats didn't demolitionde part and fast eners not listde on the introduction



A7	Flat washer ø10	8
A6	Socket Cap inner hex screw M10*30	4
A5	Self lock nut M12	4
A4	Screw cap	8
A3	Drum gasket	8
A2	Spring washer φ10	4
A1	Outer hex screw M10*60	4
03	Connector	1
02	The dumbbell bracket	1
01	Main frame	2
Number	Name	Quantity